

Tuning part Fuselage 1 for small motors

Print the Fuselage 1 with LW PLA and the Motormount with PLA or better Tough PLA. Glue the motormount from the inside well and large into the fuselage. Trace the holes of your motor and drill (or melt with a hot wire) and screw it from the inside.

IMPORTANT: make sure that the motor does not get hot! It is only for short climbs, the RISE nano is primarily a glider.

Always keep it away from you (and other people) when starting the motor!

